

# **CCS-CMx CCS Chairman Unit**



The CCS-CMx CCS Chairman Units are equipped with enhanced functionality that enables the user to take the role of chairman in a conference or meeting.

### **Functions**

#### Priority button for chairman microphone

In addition to the 'microphone on' button the chairman units feature a 'chairman priority' button. When pressed the priority button causes all currently active delegate microphones to be temporarily or permanently muted.

# Temporary or permanent muting of delegate microphones

The 'chairman priority' button can be set to mute delegate microphones on a temporary or permanent basis. On the temporary setting, delegate microphones are muted only as-long as the chairman has the priority button pressed down. On the permanent setting delegates must reactivate their microphone after a 'chairman priority' announcement by pressing the 'microphone on' button on their delegate unit. Activation of the permanent mute option is carried out by setting an internal switch, which can be accessed by removing a small plastic plate on the base of the chairman unit.

- Incorporates all functions of the CCS-Dx CCS Delegate Units (with the exception of the Possible-To-Speak functionality/LED)
- Priority button for chairman microphone
- Temporary or permanent muting of delegate microphones
- Optional chime tone facility for preceding chairman announcements
- Modern, unobtrusive styling to match the CCS-Dx CCS Delegate Units
- Available with standard or extended length microphone stems

# Optional chime tone facility for preceding chairman announcements

An optional chime tone can be selected to precede chairman priority calls. Activate the chime tone option by setting an internal switch; this can be accessed by removing a small plastic plate on the base of the chairman unit.

# Standard or extended length microphone stems

The chairman units are available with standard 313 mm (12.3 in) or extended 488 mm (19.2 in) microphone stem lengths.

#### **Controls and Indicators**

- Microphone on/off button
- Chairman priority button
- Rotary volume control for adjusting headphone volume
- Loudspeaker, automatically muted when microphone is on and/or headphones are connected
- Internal switch for selection of chairman announcement chime tone
- Internal switch for temporary or permanent muting of delegate microphones when chairman priority button is pressed
- Microphone has 'on' indicator (red LED)
- Light ring indicator on microphone stem, lights up red when microphone is on
- No Possible-To-Speak functionality and indicator is required because a Chairman Unit can always switch-on the microphone, no matter the number of delegates speaking

#### Interconnections

- 1 x 2 m (78.7 in) cable terminated with a molded 7-٠ pole circular male connector, for loop-through interconnection to delegate unit or Control Unit
- 1 x 7-pole circular female connector for loop-through interconnection to delegate units
- 2 x 3.5 mm (0.14 in) stereo headphone sockets .

### **Certifications and Approvals**

Region	Certification
Europe	CE

# **Technical Specifications**

#### Mechanical

Dimensions unit without microphone (H x W x D)	71 x 220 x 140 mm (2.8 x 8.7 x 5.5 in)		
Height with microphone in horizontal position	134 mm (5.3 in)		
Length of microphone	CSS-CMS	CCS-CML	
from mounting surface	313 mm (12.3 in)	488 mm (19.2 in)	
Weight	approx. 1 kg (2.2 lb)		
Mounting	tabletop (portable or fixed)		
Material (top)	polymer		
Material (base)	painted metal		
Color (base)	charcoal (PH10736)		
Color (top)	charcoal (PH10736)		

# **Ordering Information**

<b>CCS-CMS CCS Chairman Unit Short</b> <b>Microphone</b> microphone stem length 313 mm (12.3 inch)	CCS-CMS
<b>CCS-CML CCS Chairman Unit Long</b> <b>Microphone</b> microphone stem length 488 mm (19.2 inch)	CCS-CML
Accessories	
DCN-DISCLM Cable Clamp (25 pcs) 25 pieces	DCN-DISCLM

Americas: Bosch Security Systems, Inc. 130 Perinton Parkway Fairport, New York, 14450, USA Phone: +1 800 289 0096 Fax: +1 585 223 9180 security.sales@us.bosch.com www.boschsecurity.us

Europe, Middle East, Africa: Bosch Security Systems B.V. P.O. Box 80002 F.O. Box 80002 5600 JB Eindhoven, The Netherlands Phone: + 31 40 2577 284 Fax: +31 40 2577 330 emea.securitysystems@bosch.com www.boschsecurity.com

Asia-Pacific: Repr Robert Bosch (SEA) Pte Ltd, Security Systems 11 Bishan Street 21 Singapore 573943 Phone: +65 6258 5511 Fax: +65 6571 2698 per security nuclear check per Represented by

apr.securitysystems@bosch.com www.boschsecurity.com

 $\circledast$  Bosch Security Systems Inc. 2010 | Data subject to change without notice T6249531019 | Cur: en-US, V8, 2 Dec 2010